

CONVECTORS

"Click" on part number to view price and availability
www.morelectricheating.com

DBA/SHA

Description	Part Number			
	120V	208V	240V	277V
*Element (100 watts/ft.) 28" Heater	1802-2001-047	1802-2001-048	1802-2001-049	1802-2001-050
3'	1802-2001-053	1802-2001-054	1802-2001-055	1802-2001-056
4'	1802-2001-059	1802-2001-060	1802-2001-061	1802-2001-062
5'	1802-2001-065	1802-2001-066	1802-2001-067	1802-2001-068
6'	1802-2001-071	1802-2001-072	1802-2001-073	1802-2001-074
8'	—	1802-2001-077	1802-2001-078	1802-2001-079
10'	—	1802-2001-081	1802-2001-082	1802-2001-083
*Element (125 watts/ft.) 28" Heater	1802-2001-085	1802-2001-086	1802-2001-048	1802-2001-049
3'	1802-2001-087	1802-2001-088	1802-2001-054	1802-2001-055
4'	1802-2001-089	1802-2001-090	1802-2001-060	1802-2001-061
5'	1802-2001-091	1802-2001-092	1802-2001-066	1802-2001-067
6'	1802-2001-093	1802-2001-094	1802-2001-072	1802-2001-073
8'	—	1802-2001-095	1802-2001-077	1802-2001-078
10'	—	1802-2001-096	1802-2001-081	1802-2001-082
*Element (150 watts/ft.) 28" Heater	1802-2001-051	1802-2001-001	1802-2001-000	1802-2001-052
3'	1802-2001-057	1802-2001-007	1802-2001-006	1802-2001-058
4'	1802-2001-063	1802-2001-013	1802-2001-012	1802-2001-064
5'	1802-2001-069	1802-2001-019	1802-2001-018	1802-2001-070
6'	1802-2001-075	1802-2001-025	1802-2001-024	1802-2001-076
8'	—	1802-2001-031	1802-2001-030	1802-2001-080
10'	—	1802-2001-035	1802-2001-034	1802-2001-084
*Element (188 watts/ft.) 28" Heater	1802-2001-005	1802-2001-002	1802-2001-001	1802-2001-000
3'	1802-2001-011	1802-2001-008	1802-2001-007	1802-2001-006
4'	1802-2001-017	1802-2001-014	1802-2001-013	1802-2001-012
5'	1802-2001-023	1802-2001-020	1802-2001-019	1802-2001-018
6'	1802-2001-029	1802-2001-026	1802-2001-025	1802-2001-024
8'	—	1802-2001-032	1802-2001-031	1802-2001-030
10'	—	1802-2001-036	1802-2001-035	1802-2001-034
*Element (250 watts/ft.) 28" Heater	1802-2001-004	1802-2001-003	1802-2001-002	1802-2001-001
3'	1802-2001-010	1802-2001-009	1802-2001-008	1802-2001-007
4'	1802-2001-016	1802-2001-015	1802-2001-014	1802-2001-013
5'	1802-2001-022	1802-2001-021	1802-2001-020	1802-2001-019
6'	1802-2001-028	1802-2001-027	1802-2001-026	1802-2001-025
8'	—	1802-2001-033	1802-2001-032	1802-2001-031
10'	—	1802-2001-037	1802-2001-036	1802-2001-035
Linear Limit 28" Heater	4520-0007-007	4520-0007-007	4520-0007-007	4520-0007-007
3'	4520-0007-008	4520-0007-008	4520-0007-008	4520-0007-008
4'	4520-0007-009	4520-0007-009	4520-0007-009	4520-0007-009
5'	4520-0007-010	4520-0007-010	4520-0007-010	4520-0007-010
6'	4520-0007-011	4520-0007-011	4520-0007-011	4520-0007-011
8'	4520-0007-012	4520-0007-012	4520-0007-012	4520-0007-012
10'	4520-0007-013	4520-0007-013	4520-0007-013	4520-0007-013

* 1, 2, or 3 elements may be required. Voltage and wattage are stamped on end of elements. Divide the wattage by the heater length (feet) to determine watts/foot of element. Then use this data to determine part number of heating element.

Built-in Controls (Optional)

Description	Part Number
Disconnect Switch	410170001
Thermostat: 2-Stage	5813-0023-000
1-Pole	5813-0024-000
2-Pole	5813-0023-000
Transformer Relay: 120V	R13700002B001
208V	R13700002B002
240V	R13700002B003
277V	R13700002B004
Power Relay: 24V	5018-2006-000
120V	5018-2006-001
208V/240V	5018-2006-002
277V	5018-2006-003